






7178.0430

Onderdelen informatie
Erzatzteil information
Spare part information
Information de pièces







POS:	Art.No.:	Omschrijving:	Aantal:
1		Worktop	1
2		Back Panel	1
3		Right Side Panel	1
4		Bottom Table	1
5		Cable Gland	1
6		Cable Fixing Part	1
7		Electrical Inlet Pipe	1
8		Elc. Instalation Fixing Part	1
9	9289.0740	Electrical Terminal	1
10	9289.0045	Position Switch	4
11	9289.0405	Adjustable Legs	4
12		Nether Hinge	1+1
13		Legs Fixing Part	2
14		Front Support	1
15		Front Panel Fixing Part	1
16		Door Inner Part	2
17		Door Outer Part	2
18	9289.0410	Door Handle	2
19	9289.0650	Knob	4
20		Front Panel	1
21		Upper Hinge	1+1
22		Left Side Panel	1
23	9289.0725	Magnet	2
24		Magnet Holder	1
25	9289.0040	Plate Heaters	2
26		Hotplate Fixing Part	4
27	9289.0305	Plate Heaters	2
28	9289.0280	Iron Cast Chimney	2