



Spare part information


7543.0040





7543.0040







Spare part list 7543.0040

POS:	Art.No.:	Omschrijving:	Aantal:
4	CS9341.2400	Fan motor	1PC
8	CS9341.2400	O type heater	1PC
12	CS9341.2410	Lamp	1pc
16	**	Toast rack shelf	1SET
18	CS9341.2415	Silicone twig	1PC
20-35	**	door set	1SET
—	**	baking tray	1PC
27	**	Toast rack	1PC
36	**	Water tray	1PC
38	**	feet with screw	1SET
44-51	**	water tank set	1SET
52	CS9341.2420	knob for thermostat /function /timer	1SET
53	CS9341.2425	Power indicator	1PC
54	CS9341.2435	Temperature indicator	1PC
56	CS9341.2430	timer	1PC
57	CS9341.2440	Function switch	1PC
58	CS9341.2445	thermostat	1PC
65	CS9341.2450	Thermal cut-off	1PC
69	CS9341.2455	Thermal cut-off	1PC
		## = Parts cannot be ordered separately.	
		** = No article number known, must be requested specifically.	



This image shows a single page of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page, leaving small margins at the top and bottom. There are no vertical margin lines, text, or other markings on the page.



7543.0040

Combisteel BV

Lichtschip 63
3991CP Houten
The Netherlands

+31 (0)30 285 00 90
info@combisteel.com
www.combisteel.com